

## **WIITHINK WTB-797DAB SYSTEM SETTINGS**

---

In FM / DAB mode there is an option menu.

Press and hold **[MENU]** (4) to access to the options.

Press the **[TUNE +/-]** buttons (5/6) to navigate into the options.

Press **[ENTER]** (3) to select the options.

**DRC** (Dynamic Range Compression): This function reduces the differences between the loudest and quietest audio being broadcast.

**PRUNE:** Removes all invalid stations indicated in the station list with a “?” in front of the station name.

**SYSTEM SETTINGS** menu you can choose:

**TIME:** (to confirm press the **[ENTER]** (3) button each time )

Press and hold **[MENU]** (2) to access to the menu;

Press the **[TUNE +/-]** buttons (5/6) to select “System SETTINGS”;

Confirm with the **[ENTER]** button (3);

Press the **[TUNE +/-]** buttons (5/6) to select “Set Time/Date”;

Press the **[TUNE +/-]** buttons (5/6) to adjust the hour;

Press the **[TUNE +/-]** buttons (5/6) to adjust the minutes;

Press the **[TUNE +/-]** buttons (5/6) to set Date;

**Set 12/24 Hour:** Press the **[TUNE +/-]** buttons (5/6) to set 12 or 24hour;

**Set Date format:** Press the **[TUNE +/-]** buttons (5/6) to set DD-MM-YYYY or MM-DD-YYYY.

### **ALARM:**

Select Alarm 1 or 2;

Press **[ENTER]** button (3) to run Alarm wizard.

Press the **[TUNE +/-]** buttons (5/6) to select “On or OFF”;

Confirm with the **[ENTER]** button (3);

You navigate in this menu with **[TUNE +/-]** buttons (5/6) , Confirm with the **[ENTER]** button (3);

Select Alarm ON, , Frequency of alarm (daily, once etc), Wake up time, Source (Buzzer/DAB/FM), Volume setting, Duration (15/30/45 etc).

After select Alarm on to confirm all previous operations .

**To turn ON or OFF alarm (in stand by mode):** In stand by mode, press **[EQ/RPT]** (10) button to turn ON/OFF alarms.

**SLEEP:** in ON mode, enter MENU mode, SLEEP setting, you can select 15/30/45/60/90 minutes , press **[ENTER]** button (3) to confirm.

**Auto Update:** you can choose radio can update Date/time.

Press the **[TUNE +/-]** buttons (5/6) to select From Any/DAB/FM or no update;

**BACKLIGHT:** select with **[TUNE +/-]** button (5/6) BACKLIGHT, press **[ENTER]** (3) to enter, select with **[TUNE +/-]** button (5/6) following info:

**DIM LEVEL:** you can choose dimmer level. select with **[TUNE +/-]** button (5/6) desired level.

**On level:** indicates the brightness level of the display when the device receives commands.

**FACTORY RESET:** in SYSTEM SETTINGS, select with **[TUNE +/-]** button (5/6) YES to Factory settings.